

# OBD CABLE ADAPTERS

**CARS**

For TRUCKS diagnostic products please contact your local distributor

**auto-com**<sup>®</sup>



2+2 VAG, OBD test cable  
Part no: 900 200 650



14-pin, MB Sprinter + VW LT, OBD test cable  
Part no: 900 200 651



10-pin Opel, OBD test cable  
Part no: 900 200 652



2-pin PSA, OBD test cable  
Part no: 900 200 653\*



30-pin PSA, OBD test cable  
Part no: 900 200 654



11 pin Renault, OBD test cable  
Part no: 900 200 655



10-pin SAAB, OBD test cable  
Part no: 900 200 656



3-pin Fiat, OBD test cable  
Part no: 900 200 657\*



20-pin BMW, OBD test cable  
Part no: 900 200 658



38-pin MB, OBD test cable  
Part no: 900 200 659



FVV, Ford, Volvo, Audi and VW, OBD test cable  
Part no: 900 200 660\*



38-pin Iveco OBD test cable  
Part no: 900 200 673